

3/10/25

Experiment 10 a

Internetworking with routers in Cisco packet tracer simulator.

AIM: Internetworking with routers in Cisco packet tracer simulator, design a simple network with 1 router and 2 PCs using Cisco packet tracer.

Procedure :

1) Configure Router:

- * Go to CLI \rightarrow enable \rightarrow config t
- * Set IP for Fast Ethernet 0/0 : 192.168.10.1
255.255.255.0 \rightarrow no shutdown
- * Set IP for Fast Ethernet 0/1 : 192.168.20.1
255.255.255.0 \rightarrow no shutdown

2) Configure PCs:


- * PC0 : IP 192.168.10.2, Gateway 192.168.10.1
- * PC1 : IP 192.168.20.2, Gateway 192.168.20.1

3) Connect Devices

- * PC0 \rightarrow Router Fast Ethernet 0/0 (copper straight-through)
- * PC1 \rightarrow Router Fast Ethernet 0/1 (copper straight-through)

4) Test connectivity:

- * ping from PC0 to PC1 to verify network connection.



Experiment 10 b

Aim: configure a network with a wireless router, DHCP server and internet connection.

Procedure :


- 1) * Add wireless router, PC, Laptop, cable Modem, Internet cloud, cisco.com server.
- * Connect using copper and coaxial cables as required.
- 2) configure wireless Router :
 - * set SSID : Home Network
 - * enable DHCP & set DNS : 208.67.220.220.
- 3) configure Laptop & PC
 - * Laptop : Install wireless module \rightarrow connect to Home network.
 - * PC : Enable DHCP \rightarrow get IP automatically from routes.
- 4) configure cisco.com server :
 - * Enable DHCP & DNS services with IP : 208.67.220.220.

* set pool and global gateway settings.

Verify connectivity:

* Refresh IP on pc (ipconfig /release → ipconfig /renew)

* ping disco.com to test internet connection



Student observation

D) write down the key features of configuring wireless routes & DHCP server.

A) wireless Router: provides wi-fi, sets SSID, connects devices.

DHCP server : Automatically assigns IP, subnet, DNS.

2) What is the significance of DHCP server in Internetwork - ping ?

- A) * Simplifies IP assignment & avoids conflicts
* Ensures smooth network communication.

3) Design & configure an Internetwork in your lab using switch, router & Ethernet cables.
Draw & label.

- A) * Setup : Router → switch → PCs (Ethernet cables)
eg)
* Router : 192.168.1.1
* PC₀ : 192.168.1.2, Gateway : 192.168.1.1
* PC₁ : 192.168.1.3, Gateway : 192.168.1.1
* Test : ping between PCs to verify connection

Result : Internetworking with routers in Cisco packet tracer simulator is done successfully.

✓ 91/100



DHCP server : Automatically assigns IP, gateway, subnet, DNS.

Q) what is the significance of DHCP server in Internetwork - ping ?

- A) * Simplifies IP assignment & avoids conflicts
* Ensures smooth network communication.

Q) Design & configure an internetwork in your lab using switch, router & Ethernet cables.
Draw & label.

- A) * Setup : Router → switch → PCs (Ethernet cables)
eg)
* Router : 192.168.1.1
* PC₀ : 192.168.1.2, Gateway : 192.168.1.1
* PC₁ : 192.168.1.3, Gateway : 192.168.1.1
* Test : ping between PCs to verify connection

Result : Internetworking with routers in cisco packet tracer simulator is done successfully.